



Dimensions

Fixing Type	A (mm)	B (mm)	C (mm)	D (mm \varnothing)	E (Max mm)	Part Code
Metric & Wood Thread Included	6	10	10-20	52	24	6000.22.010
Metric & Wood Thread Included	6	10	8-20	45	46	6000.22.020

The Hole in the Wall

Timber Thread - Thread can be drilled straight into substrate

Metric Thread - A hole needs to be pre-drilled, emptied and filled with anchor resin before fitting the thread in place. Anchor resin needs to set before installing system. Look at your resin instructions for guidance.

To install the Glass Adaptor

1. Fix the thread into substrate as described above
2. Attach the standoff section (the larger of the two metal pieces) to the thread and push as close to the substrate as possible
3. Place glass onto thread, with the thread fixing through the 25mm hole
4. Finally screw on the face of the Glass Adaptor to firmly secure the glass

Template for Glass

