

WARNING!**THIS ADHESIVE SETS VERY QUICKLY AND IS VERY STRONG**

- Remove cap.
- Place nozzle on the end and twist into secure position.
- Push down on the syringe plunger.
- Apply mixed adhesive liberally to the inside of the female part.
- Push the male part in, twisting as you push if possible to distribute the adhesive evenly around the joint.
- Bring to rest in required position and wipe any excess from the outside of the joint with a wipe/paper towel.
- Leave for 20 minutes before moving, by which time handling strength will have been reached. Full cure will take place over 24 hours.
- Leave nozzle on the syringe to provide a seal to stop air getting into the cartridge as the adhesive will have set.



For further help fitting your balustrade system or for any other enquiry, please contact SWR using the details below.